

MARCH PUMPS

1819 PICKWICK AVE., GLENVIEW, IL 60026-1306, U.S.A PHONE: (847) 729-5300 - FAX: (847) 729-7062 WWW.MARCHPUMP.COM

815 HOT WATER PUMPS

<u>DESCRIPTION & OPERATION:</u> The March 815 Series hot water booster centrifugal magnetic drive pumps are built to handle liquid transfer in heating and cooling operations. Contact the factory for application assistance. Pumps are not self-priming, lack a suction lift, and thus require a flooded suction. Pumps cannot be run dry.


<u>INSTALLATION:</u> The 815 Series pumps should be installed with the pump housing arrow pointing in the direction of flow within the system. If the arrow indicating flow is not in the direction required, remove the housing screws holding the housing to the motor bracket and rotate the housing assembly as required. Replace the screws and tighten. The pump is composed of a wet end assembly which can be separated by unscrewing the housing screws. The pump will then separate into 2 parts. The liquid will be contained within the wet end assembly unless the rear housing screws on the rear housing are loosened.

<u>LUBRICATION</u>: The motor should be oiled annually at the start of the heating season with 4 or 5 drops of SAE 20 weight non-detergent oil in each bearing. If the pump is used year round it should be oiled every six months. Do not over oil.


<u>GENERAL SAFETY INFORMATION:</u> Follow all local electrical and safety codes, and the Occupational Safety and Health Act (OSHA). Make certain that the power source conforms to the requirements of your equipment. Always disconnect power source before performing any work on or near the electric motor. Caution must be exercised to relieve any pressure in the system and in draining hot water from the pump or the system. March cannot recommend the 815 Series out of bronze where the liquid is used for human consumption per California Law due to the presence of lead.


*UL Recognition on pumps, file E80954, is for water only. (815-BR, 815-PL) Motors are U.L. Yellow Card listed, impedance protected or thermal overload Protected. Complete pump under U.L. file E80954.

ELECTRICAL: Motors are available in different electrical configurations such as 115 Volt 50/60 Hz or 230 Volt 50/60 Hz, 1 Phase and rated for continuous duty. 115 Volt models 815-BR, 815-PL, & 815-SS have a conduit box, 230 Volt have a 3 foot (0.9 m) cord. 115 Volt models 815-BR-C, 815-PL-C, & 815-SS-C have a 6 foot (1.8 m) cord with plug, 230 Volt models have a 3 foot (0.9 m) cord. Motors are air cooled.



SPECIFICATIO	NS	[
MODELS					815-PL			815-SS			815-BR-C			815-PL-C			815-SS-C		
	5 V	0809-0058-0400		0809-0017-0200			0809-0215-0900			0809-0017-0400			0809-0188-0100			0809-0198-0100			
23	0 V	0809-0017-0100		0809-0017-0300			0809-0215-1100			0809-0017-0500			0809-0188-0200			0809-0198-0200			
Abbreviation	viations	BR: Bronze			PL: Polysulfone			SS: Stainless			BR: Bronze			PL: Polysulfone			SS: Stainless		
		Inline Inlet		Inline Inlet		Inline Inlet		C: Center Inlet		C: Center Inlet		C: Center Inlet							
	ITS			50 Hz	60 H		0 Hz	60 H		50 Hz	60 H		0 Hz	60 H		50 Hz	60 H		0 Hz
Max F	low	J.		2.7 lpm	7 gp		.7 lpm	7 gpi		2.7 lpm	8 gp		0 lpm	8 gp		0 lpm	8 gp		0 lpm
Max Head		18.6 ft / 8.05 psi 4.1 m		18.6 ft / 8.05 psi 4.1 m		18.6 ft / 8.05 psi 4.1 m		18.6 ft / 8.05 psi 4.1 m		18.6 ft / 8.05 psi 4.1 m		18.6 ft / 8.05 psi 4.1 m							
Inlet		1/2" MPT			1/2" MPT			1/2" MPT			3/4" MPT		3/8" FPT & 3/4" MPT		3/4" MPT				
Outlet		1/2" MPT			1/2" MPT			1/2" MPT			1/2" MPT		1/2" MPT		1/2" MPT				
					50 psi / 3.4 bar Max				150 psi / 10 bar Max										
	nperature 250 °F / 121 °C Max											250 °F / 121 °C Max							
Packed We	_	_		os / 2.7 kg		5 lbs / 2.3 kg		6 lbs / 2.7 kg		6 lbs / 2.7 kg		5 lbs / 2.3 kg		6 lbs / 2.7 kg					
ELECTRICAL 60			Hp	Rpm	Α	Hp	Rpm	Α	Hp	Rpm	Α	Hp	Rpm	Α_	Hp	Rpm	Α	Hp	Rpm
	5 V 0 V	1.4 0.7	1/25		1.4 0.7	1/25	3450 3450	1.4 0.7	1/25		0.5	1/25 1/25	3450 3450	0.5 0.7	1/25	3450 3450	0.5	1/25	3450 3450
ELECTRICAL 50	_	• • • •	kW			kW		A	kW		Α	kW			kW			kW	
		A	0.029	Rpm 2850	A	0.029	Rpm 2850	1.4	0.029	Rpm 2850	0.4	0.022	Rpm 2850	A	0.022	Rpm 2850	A	0.022	Rpm 2850
115 V 230 V		0.7	0.02		0.7	0.029	2850	0.7	0.029		0.7	0.022	2850	0.4	0.022		0.7	0.022	2850
Overall Pump S	_		W	1	<u> </u>	W	1	H	W	L	H	W	1	<u> у., /</u>	W	1	H	W	1
Inc	hes		3.33	7.74	5.31	3.38	7.74	5.31	3.33	7.74	4.50	4.18	8.75	4.38	4.18	8.25	4.50	4.18	8.69
115 V	cm	13.4	8.4	19.6	13.4	8.5	19.6	13.4	8.4	19.6	11.4	10.6	22.2	11.1	10.6	20.9	11.4	10.6	22.0
230 Inc	hes	4.87	3.33	7.74	4.88	3.38	7.74	4.87	3.33	7.74	4.50	3.50	8.94	4.37	3.50	8.43	4.50	3.50	8.62
230	cm	12.3	8.4	19.6	12.3	8.5	19.6	12.3	8.4	19.6	11.4	8.8	22.7	11.0	8.8	21.4	11.4	8.8	21.8
All specifications & data are based on pumping water & are intended as a guideline only. Specifications may vary with different motors.																			





#	DESCRIPTION	815-BR-C	815-PL-C	815-SS-C	SIZE (Inches)	QTY.	815-BR-C	815-PL-C	815-SS-C
Α	Screw (Housing)	Steel Steel Stainless		#8-32 x 1 Lg.	4	0923-00	0809-0205-1000		
В	Pump Housing	Bronze Polysulfone Stainless		Center Inlet	1	0809-0142-0000	0809-0179-0100	0809-0150-0010	
С	Hex Nut		Stainless			4			0991-0004-1000
D	"O" Ring		Silicone		0.070 CS x 2.441 ID	1	0809-0165-1000		0809-0165-1000
Е	"O" Ring		Silicone		1/16 CS x 2-3/8 ID	1		0809-0027-1000	
F	Thrust Washer		Teflon			1		0809-0043-1000	
G	*Shaft		Stainless		"D" Flat	1		0809-0161-1000	
Н	*Shaft		Stainless		Left-Hand Thread	1	0809-0214-1000		0809-0214-1000
- 1	Impeller	Ry	ton/Teflon/Gla	SS	2-5/32 Dia.	1		0809-0107-0200	
J	Rear Housing		Stainless			1		0809-0012-1000	
Κ	Screw (Rear Housing)		Stainless		#8-32 x 3/8 Lg.	4	0135-00	40-1000	
L	Screw		Stainless		#8-32 x 1 Lg.	4			0809-0205-1000
	Drive Magnet					1		0125-0083-0100	
Ν	Screw		Stainless		#8-32 x 3/8 Lg.	4		0135-0040-1000	
0	Washer		Stainless		#8	4		0858-0004-1000	
Р	Motor Bracket		Plastic			1		0809-0058-1000	
Q	Motor 115 V, 50/60 Hz				w/Cord, Base, Plug	1		0809-0218-1000	
R	Motor 230 V, 50/60 Hz				w/Cord & Base	1		0809-0124-1000	

DISASSEMBLY & REASSEMBLY

The motor can be removed from the wet end assembly without draining the liquid from the system. To do so remove four housing screws and slide the motor assembly away. If parts inside the wet end assembly must be removed, isolate the pump or drain the system. When the system is drained and cool, remove the four rear housing screws from the rear of the housing. The rear housing can now be removed. Remaining pump parts can be removed. Replace any worn or damaged parts. Replace the "O" ring anytime the rear housing is removed.

NOTE: Contact Factory for other materials and/or parts not listed.

0809-0053-1200 R7

*Check shaft type before ordering replacement parts.

<u>LIMITED WARRANTY:</u> March pumps are guaranteed only against defects in workmanship or materials for a period of one year from date of manufacture pumping water. For the complete warranty and to register online go to www.marchpump.com/warranty-registration